AS 1428.2 COMPLIANT

ABOVE Ground Plumbing Connection

BELOW Ground Plumbing Connection

All dimensions are in mm

315

65

Side Pod (front view)

220

805

15

Water Inlet

Waste Water Outlet Max 260 mm from ground

External Isolation Valve (Recommended - not supplied) Connect **before** installation

Waste Water Outlet

30

40

10

180

60

70

18
22

315

65

Side Pod (front view)

220

805

External Isolation Valve (Recommended - not supplied) Connect **before** installation

15

40

Water Inlet

Waste Water Outlet

60

70

18
22

180

300

Side Pod (side view)

230

100

DOG BOWL ground

Internal Base Mounting Plate

280

Ø15

180

Front of unit will end up here (between two holes)

- Place Base Mounting Plate (BMP) halves in position on the installation surface.

  Position the BMP so that the Front of the unit will be in the middle of 2 holes.
- Mark anchor points on the surface through BMP holes and drill out.
- Fit off either 12 mm threaded rods or 16 mm dynabolts*
- Remove PVC S-Trap inside to gain access to the base of the unit.
- Place unit over anchors, then place BMP halves back inside unit over anchors and secure in place.

  * Indicates correct gauges for anchor system types listed; choice of anchor system is at installer's discretion

Code: ABUA138HFD & AB2UA148HFD

Location of Water Onlet & Water Outlet

Locate Water Inlet & Water Outlet at back of unit (out of view), or at either side if necessary.

WALL

Do not place Water Inlet & Water Outlet under the Side Pod: this will obstruct wheelchair access.

Front Pod

1300 213 774
www.aquabubbler.com.au

0800 213 774
www.aquabubbler.co.nz

LEAD FREE
SAFE BRASS

WaterMark