ABOVE Ground Plumbing Connection

BELOW Ground Plumbing Connection

All dimensions are in mm

DOG BOWL ground

230 · 100

315 · 65 · 220 · 805 · 15

315 · 65 · 220 · 805 · 15

Internal Base Mounting Plate

280 · Ø15 · 180

Front of unit will end up here (between two holes)

- Place Base Mounting Plate (BMP) halves in position on the installation surface.

  Position the BMP so that the Front of the unit will be in the middle of 2 holes.
- Mark anchor points on the surface through BMP holes and drill out.
- Fit off either 12 mm threaded rods or 16mm dynabolts*
- Remove PVC S-Trap inside to gain access to the base of the unit.
- Place unit over anchors, then place BMP halves back inside unit over anchors and secure in place.

* Indicates correct gauges for anchor system types listed; choice of anchor system is at installer's discretion

Waste Water Outlet Max 260 mm from ground

External Isolation Valve
(Recommended - not supplied)
Connect **before** installation

External Isolation Valve
(Recommended (not supplied)
Connect **before** installation

Water Inlet · **Waste Water Outlet**

Water Inlet · 40 · **Waste Water Outlet**

30 · 40 · 10 · 180 · 60 · 18 · 22 · 70

180 · 60 · 18 · 22 · 70

15

Location of Water Inlet & Waste Water Outlet

Locate Water Inlet & Waste Water Outlet at back of unit (out of view), or at either side if necessary.

WALL ✓✓✓ ✓ ✓ ✓ ← Front Pod

Code: AB128HFD

1300 213 774
www.aquabubbler.com.au

0800 213 774
www.aquabubbler.co.nz

SAFE BRASS

WaterMark