


ABOVE Ground Plumbing Connection


BELOW Ground Plumbing Connection



ROUGH IN with Internal Base Mounting Plates (IBMP)


IMPORTANT: Installed unit must have $\geq 150\text{mm}$ clearance from ALL walls.

- A.** Place the IBMP on **LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


- B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



- C. PLACE UNIT** over anchors.




- D. LOWER IBMP** inside the unit over the anchors and secure.



Check that ground is level

If ground is NOT LEVEL, recess a level area as suggested:


Ensure all edges are beveled to avoid trip hazard



LEVEL installation surface

Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.



- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.