



**ABUA136 Schematic**  
(670mm height)



**ABUA137 Schematic**  
(770mm height)



**ABUA138 Schematic**  
(870mm height)



**ABUA1310 Schematic**  
(1020mm height)



**Accessories  
Schematic**






## ABOVE Ground Plumbing Connection

## BELOW Ground Plumbing Connection


All dimensions are in mm



### ROUGH IN with Internal Base Mounting Plates (IBMP)


**IMPORTANT:** Installed unit must have  $\geq 150\text{mm}$  clearance from ALL walls.

- A. Place the IBMP on LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


- B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



- C. PLACE UNIT** over anchors.




- D. LOWER** IBMP inside the unit over the anchors and secure.



### Check that ground is level

If ground is NOT LEVEL, recess a level area as suggested:


Ensure all edges are beveled to avoid trip hazard



LEVEL installation surface

### Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.




- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.



## ABOVE Ground Plumbing Connection

## BELOW Ground Plumbing Connection


All dimensions are in mm



## ROUGH IN with Internal Base Mounting Plates (IBMP)


**IMPORTANT:** Installed unit must have  $\geq 150\text{mm}$  clearance from ALL walls.

- A. Place the IBMP on LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


- B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



- C. PLACE UNIT** over anchors.




- D. LOWER** IBMP inside the unit over the anchors and secure.



## Check that ground is level

If ground is NOT LEVEL, recess a level area as suggested:


Ensure all edges are beveled to avoid trip hazard



LEVEL installation surface

## Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.




- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.



## ABOVE Ground Plumbing Connection


## BELOW Ground Plumbing Connection



## ROUGH IN with Internal Base Mounting Plates (IBMP)


**IMPORTANT:** Installed unit must have  $\geq 150\text{mm}$  clearance from ALL walls.

- A. Place the IBMP on LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


- B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



- C. PLACE UNIT** over anchors.




- D. LOWER** IBMP inside the unit over the anchors and secure.



## Check that ground is level

If ground is NOT LEVEL, recess a level area as suggested:


Ensure all edges are beveled to avoid trip hazard



LEVEL installation surface

## Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.




- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.



## ABOVE Ground Plumbing Connection


## BELOW Ground Plumbing Connection



## ROUGH IN with Internal Base Mounting Plates (IBMP)


**IMPORTANT:** Installed unit must have  $\geq 150\text{mm}$  clearance from ALL walls.

- A. Place the IBMP on LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


- B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



- C. PLACE UNIT** over anchors.




- D. LOWER** IBMP inside the unit over the anchors and secure.



## Check that ground is level

If ground is NOT LEVEL, recess a level area as suggested:


Ensure all edges are beveled to avoid trip hazard



LEVEL installation surface


## Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.



- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.


## DOG BOWL




### To Attach Dog Bowl

Insert coach bolts through square holes (either side of Bowl)

Secure bolts from inside of unit with washer and lock nut.




## HANDS FREE PEDALS



Unit supplied with pedals attached - no assembly required.

## OUTDOOR TAP



Unit supplied with outdoor tap attached - no assembly required.

## EXTERNAL CHILLER



More information on the external chiller available upon request