# Wall Drinking aquaBUBBLER Installation Guide

[Version 11: Jul 2024] Get the latest version at bit.ly/wd-installation





# ★ IMPORTANT ★



- 1. Unit must be installed by a **Certified Plumber**
- 2. Installation must be in accordance with

#### AS/NZS 3500.1 & AS/NZS 3500.2

max water pressure 1000 kPa, max temp 40°C

Nonadherence to any of the above, or failure to follow the steps detailed in this guide, will VOID ALL WARRANTIES

#### Install onto:



### **Prepare Connection Points for installation**



**Use Hanging Screw** point (50mm below the desired height of the wall drinking dish) as reference to prepare the location of

#### Water Outlet and Water Inlet

More Details on Schematic >


Area available for Water Supply 17x17mm (1/2"BSP)

### Disassemble Wall Bracket from Lid & Moulded Body

• Lay unit on it's back on a table. Remove 4 x Security Screws around the Stainless Steel lid with the T30 Post Torx Screwdriver (supplied).




• Lift the lid slightly away from the molded body. Disconnect the water dispenser supply line by holding back the grey collet ring on the bottom of the water dispenser and pulling out the black tubing.



Product Code: ARWD22

- After disconnect the lid, remove 4 x PH screws to release unit body from the internal wall bracket.
- Lift the molded body off internal wall bracket.



# **Set up Hanging Screw & Connection Points**

Consult SCHEMATIC - bit.lv/wd23sch mark other connection points referencing the Hanging Screw (Leave head off wall surface for 2mm)



# **Connect Waste Water Outlet**

Fit off the mini P-trap (supplied) to the end of the waste water pipe with Sealant.







### Hang up Unit


Hang unit on wall over the Hanging Screw Place the internal bracket over the mini P-trap and locate the keyhole onto the hanging screw. Use a **spirit level** to set the position of bracket to the wall.

Anchor unit to wall with Screws (at least 4 corners).

- Solid wall screws + green plugs (supplied) along sides
- Stud wall Tek screws (supplied) along centre into timber stud

### **Connect Water Inlet**

Connect water inlet to 1/2"BSP connection, isolation valve and variable flow/pressure regulator. Adjust here if needed. It may need readjustment after 48 hours.



• Demonstrate the simple task of water pressure adjustment to the facilities manager to avoid an unnecessary return visit.

### Reassemble Moulded Body & Lid to Wall Bracket

• Slide molded body over bracket to the wall.



- Secure in place by re-screwing in the 4 x PH screws.
- Refit black tubing by pushing straight back into the bottom of the water dispenser with the lid.
- Rescrew 4 x Security screws around the lid.

# Finishing

Run tap and check for leaks





Leave T30 Post Torx Security Screwdriver with client





