




## ABOVE Ground Plumbing Connection

## BELOW Ground Plumbing Connection


All dimensions are in mm



### ROUGH IN with Internal Base Mounting Plates (IBMP)


**IMPORTANT:** Installed unit must have  $\geq 150\text{mm}$  clearance from ALL walls.

**A.** Place the IBMP on **LEVEL** mounting surface and mark holes. Make sure the intended Refill pod position is between (any) two holes.




REFILL POD will end up here


**B. FIT OFF** either 12mm threaded rods or 16mm dynabolts (anchors).



**C. PLACE UNIT** over anchors.




**D. LOWER** IBMP inside the unit over the anchors and secure.



### Check that ground is level


If ground is NOT LEVEL, recess a level area as suggested:

Ensure all edges are beveled to avoid trip hazard



### Determine Unit Orientation

Where possible, locate water inlet and waste water outlet on **wall side**.



- Installation must be in accordance with AS/NZS 3500.1 & AS/NZS 3500.2
- Max water pressure 1000 kPa, Max temp 40°C
- Where installed in frost-prone areas, unit must be fitted with an Anti-Freeze Valve.